

Step 1: Bracket Installation

Inside Mount Application:

Bracket Placement:

Getting Started

Tools:

Level

Pencil

Power drill

Screwdriver

Mounting

Surface

Drywall/Plaster

Wood

Metal

• Tape Measure

is installed and working to your satisfaction.

Fasteners for different mounting surface

 Measure 2" in from both ends of the head rail and mark the bracket location on the mounting surface

1 1/4" Screws (Provided)


(Not Provided

(Not Provided)

Sheet Metal Screws


Wall Anchors, Expansion Bolts


Fastener





desired position. Then, return the cord to the original position to secure the cord lock.







 Dusting Regularly dust the shade with a duster. In most

Vacuuming

Use a hand-held vacuum on low suction setting to remove dust.

Spot-Cleaning

Dampen a clean cloth with warm water and mild detergent solution and then dab the spot until stain is gone. Do not rub! Allow the fabric to dry in a fully lowered shade position.

Routine cleaning help maintain the beauty of your shades. To care for your shades use any of the following options:

situations this is the only cleaning method needed.

